

The Cables and Connecting Your ActivBoard

The Cables and Connections



- Video Graphics Array Cable (VGA)
- + 6 ft and 25 ft
- + Lengths differ *only* for convenience




- USB Cable
- + Plug and Play
- + Communication between the board and the laptop
- + Cannot be longer than 16 ft.



- Audio Cables
- + Color coded for easy connect
- + Allows sound

Connecting the Board



To ensure your computer recognizes your ActivBoard, follow these steps:

1. Turn on your computer
2. Turn on ActivBoard (check to be sure volume is down)
3. Connect cables to ActivBoard
4. Connect cables to computer (You may need to press Fn + F8)
5. Disconnect cables in any order